

## **ASSEMBLY INSTRUCTIONS:**

- 1. SLIDE THE O-RING ONTO THE FRONT END OF THE PLUG HOUSING UNTIL IT SEATS UP AGAINST THE RIDGE OF THE PLUG HOUSING.
- 2. SLIDE THE COUPLING RING OVER THE PLUG HOUSING.


  NOTE: MAKE SURE THE FRONT OF THE COUPLING RING CAN SLIDE PAST THE RIDGE ON THE PLUG
  HOUSING. IF NOT, IT IS INSERTED THE WRONG WAY.
- 3. SLIDE THE SEALING NUT, SEALING RING, AND PLUG HOUSING/COUPLING RING OVER THE FRONT END OF THE CABLE IN THE FOLLOWING ORDER:
  - 1ST. SEALING NUT. 2ND. SEALING RING.
  - 3RD. PLUG HOUSING/COUPLING RING.
- I. TERMINATE THE \*HDMI-STYLE PLUG TO THE CABLE.

  NOTE: SEE FIGURE 1 FOR \*HDMI-STYLE PLUG ASSEMBLY INSTRUCTIONS.
- 5. SLIDE THE \*HDMI-STYLE PLUG INTO THE BACK END OF THE INSERT UNTIL IT SNAPS INTO PLACE. NOTE: SEE FIGURE 2 FOR INSERT AND PLUG ALIGNMENT GUIDE.
- 6. SLIDE THE INSERT/\*HDMI-STYLE PLUG INTO THE FRONT END OF THE PLUG HOUSING UNTIL IT SNAPS INTO PLACE.
- . PUSH THE SEALING RING INTO THE REAR OF THE PLUG HOUSING.
  NOTE: NO PART OF THE SEALING RING SHOULD EXTEND PAST THE REAR OF THE PLUG HOUSING.

SEE FIGURE 3 FOR RECOMMENDED STRIPPING DETAIL.


SCREW THE SEALING NUT ONTO THE PLUG HOUSING. THE RECOMMENDED TIGHTENING TORQUE IS 10-12 IN-LBS FORCE.

NOTE: MAKE SURE THAT THE SEALING RING SQUEEZES TIGHTLY AROUND THE CABLE O.D.



\*HDMI IS A REGISTERED TRADEMARK OF HDMI LICENSING LLC CORPORATION

**Rohs Compliant** 



## \*HDMI-STYLE PLUG ASSEMBLY INSTRUCTIONS

- 1. SOLDER THE CABLE WIRES TO THE PCB BODY. SEE FIGURE 3 FOR RECOMMENDED CABLE STRIPPING DETAILS.
- 2. PLACE THE PCB BODY INTO THE FRONT SHELL AND PUSH FORWARD UNTIL IT SITS FIRMLY INTO THE FRONT SHELL.
- SNAP THE BACK SHELL ONTO THE FRONT SHELL.

SERIES

DCC-HD19

4. CRIMP THE BACK SHELL CLAMP AROUND THE CABLE JACKET.

